

# USER GUIDE PowerMaxComplete

Fully supervised wireless alarm control system





# **PowerMaxComplete User Guide**

# **Table of Contents**

| Compatibility of this Manual2                | Looking after People Left at Home    |      |
|--|--------------------------------------|------|
| Quick Guide To Primary Alarm Control         | Emergency Calls for Help             |      |
| Operations2                                  | Remote Control by Telephone          |      |
| Contact list form2                           | Reporting to Private Telephone       |      |
| Luminous Indicator Signals2                  | Remote Control by SMS                |      |
| Siren Signals3                               | Reporting by SMS                     |      |
| Useful Hints For PowerMaxComplete Users.3    | Conducting a Walk Test               |      |
| 1. Introduction4                             | 7. User Settings                     |      |
| Overview4                                    | What are the Settings You Need?      |      |
| System Features5                             | Entering the User Settings Menu      | 23   |
| Terms of the Trade6                          | Bypassing Zones                      | 24   |
| Control Pushbuttons6                         | Reviewing the Bypassed Zone List     | 25   |
| Multi-Function Transmitter7                  | Recalling the Last Bypass Scheme     |      |
| Voice Announcements7                         | Programming Private Report           |      |
| Proximity Tags8                              | Setting the User Codes               |      |
| Screen Saver Option8                         | Enrolling Keyfob Transmitters        |      |
| 2. Securing The Protected Site9              | Deleting Keyfob Transmitters         |      |
| Security-Related Pushbuttons9                | Enrolling Proximity Tags (optional)  |      |
| Partition selection process9                 | Deleting Proximity Tags              |      |
| Preparing to Arm9                            | Setting the Voice Options            |      |
| Arming 'AWAY'9                               | Automatic Arming Option              |      |
| Arming 'HOME'9                               | Setting Arming Time                  |      |
| Switching from 'HOME' to 'AWAY'10            | Enabling the Squawk Option           |      |
| Switching from 'AWAY' to 'HOME'10            | Setting Time and Time Format         |      |
| Arming 'Instant'10                           | Setting the Date and Date Format     |      |
| Forced Arming10                              | Scheduler Function                   |      |
| Arming in the Latchkey Mode11                | Installer Mode                       |      |
| Initiating a Panic Alarm11                   | 8. Reading The Event Log             |      |
| Initiating Fire Alarm11                      | Event Log Description                |      |
| Initiating Emergency Alarm11                 | Reading Procedure                    | 33   |
| Disarming and Stopping Alarms11              | 9. Maintenance                       | 34   |
| Siren Behavior12                             | Replacing the Backup Battery         |      |
| 3. Speech And Sound Control13                | Replacing Wireless Devices Batteries |      |
| Speech & Sound Cont. Push-buttons13          | Periodic Testing                     |      |
| Adjusting the Speech Volume13                | Cleaning the Control Panel           |      |
| Voice ON/OFF                                 | 10. Performance Limits               |      |
| Message Exchange                             | APPENDIX A. PARTITIONING             | 37   |
| Message Playback14                           | Selecting a Partition                |      |
| Chime ON/OFF14                               | Arming / Disarming the System        | 37   |
| 4. Electrical Appliance Control15            | The Show Function                    |      |
| Control Options and Pushbuttons15            | Siren                                | 38   |
| Automatic ON/OFF Control15                   | Partition Status display             | 38   |
| 5. Reading Alarm Memory And Trouble Data .16 | MCT-237                              | 38   |
| Reviewing Alarm/Tamper Memory16              | MCM-140+                             | 39   |
| Reviewing Trouble Information16              | MKP-150/151/152                      |      |
| Reviewing Memory & Troubles at the Same      | MKP-160                              |      |
| Time   | APPENDIX B. GLOSSARY                 | 40   |
| Correcting Trouble Situations17              | APPENDIX C. HOME FIRE ESCAPE PLAN    | NING |
| 6. Special Functions18                       |                                      | 42   |
|  |                                      |      |

# **Compatibility of this Manual**

This manual should be used with PowerMaxComplete v2.0.00 and above.

# **Quick Guide To Primary Alarm Control Operations**

| QUICK REFERENCE TO PRIMARY ALARM CONTROL OPERATIONS   |  |  |
|---|--|--|
| Active Partition Selection (when partition is enabled) 🖾 # 🛍 + 🖾 [PARTITION NO.]                                      |  |  |
| Arming AWAY + [Code]*   |  |  |
| Arming AWAY-INSTANT F [Code]* + F [Code] + L T L  |  |  |
| Arming HOME F[Code]*  |  |  |
| Arming HOME-INSTANT   |  |  |
| Arming AWAY-LATCHKEY 🖙 🛈 + [Code]* + 🖾 🛈  |  |  |
| Force Arming AWAY (system not ready) From + [Code]* + From (to silence the protest buzz)                              |  |  |
| Force Arming HOME (system not ready) + [Code]* + (to silence the protest buzz)  |  |  |
| Disarming and stopping alarms 🖙 🔟 + [Code]  |  |  |
| * The factory default master user code is 1 1 1 1. The code is not required if quick arming has been permitted by the |  |  |
| installer. Change the factory default code to a secret code without delay (see section 7)                             |  |  |

| Dear Customer, Thank you for choosing PowerMaxComplete, a highly advanced wireless alarm control system produced by Visonic Ltd.  Monitoring Station's Name Telephone Number: | installer. Change the factory default code to  | a secret code without delay (see section 7) |
|---|--|---|
| to facilitate obtaining assistance.  If you or your installer set the system to contact private telephone numbers, note down the 4  | Dear Customer, Thank you for choosing PowerMaxComplete, a highly advanced wireless alarm control system produced by Visonic Ltd. Please note below the installer's telephone number to facilitate obtaining assistance. Company Name: Telephone Number: Person to Contact: Also please make sure that you have the name and telephone number of the central station your system will report to. If you ever call the central station to ask questions, you should be able to come up with your | Monitoring Station's Name                   |

# **Luminous Indicator Signals**

from your installer and write it.

| Indicator      | Behavior        | Significance   |
|----------------|-----------------|--|
| (red)          | Lights steadily | The system / a system partition(s) is in the armed state (AWAY MODE)   |
| <b>—</b> (100) | Flashes         | The system / a system partition(s) is in the armed state (HOME MODE)   |
|                | No light        | The system is presently in the disarmed state  |
|                |                 | <b>Note (*):</b> Refers to the selected partition(s). If control panel is set to a single partition, then operation performed on other partitions will not be displayed. |
| (orange)       | Lights steadily | The system / a system partition(s) (*) is presently in a state of trouble  |
| (orango)       | No light        | No trouble - all is well   |
|                |                 | <b>Note (*):</b> Refers to the selected partition(s). If control panel is set to a single partition, then operation performed on other partitions will not be displayed. |
| (green)        | Lights steadily | The chime function is active - chime zones will chime when disturbed.  Note: The chime indicator lights steadily when at least one partition is enabled.                 |
|                | No light        | The chime function is inactive - chime zones will not chime when disturbed.  |
| (green)        | Lights steadily | AC power is supplied to the control panel  |
| (green)        | No light        | The system is operating on backup battery power  |

#### Siren Signals

| Alarm Type                  | Graphic Representation of Signal      | Verbal Description of Signal                |
|-----------------------------|---------------------------------------|---|
| Burglar / 24<br>hour/ Panic |                                       | ON continuously                             |
| Fire                        |                                       | ON - ON - ON - pause - ON - ON - ON - pause |
| Test*                       | — (both external and internal sirens) | ON for 2 seconds (once)                     |

<sup>\*</sup> Supplementary use only.

#### **Useful Hints For PowerMaxComplete Users**

**Stopping an alarm:** When the alarm sounds - press the DISARM (n) button on your key-ring transmitter or press on the keypad and then enter your access code (1 1 1 1 by default).

Stopping trouble beeps: When trouble occurs in the system, the TROUBLE indicator on the front panel will light, and a sequence of 3 beeps will sound once per minute. If you do not wish to eliminate the trouble immediately and the beeps are bothersome, press the DISARM ( ) button on your key-ring transmitter, or press on the keypad and then enter your access code (1 1 1 1 by default). This will silence the buzzer for 4 hours, after which the trouble beeps will resume sounding. Be advised, however, that in any case the trouble beeps are silenced during night hours.

Perimeter and interior zones versus 24-hour zones: Most of the protection sensors in your system are linked to perimeter and interior zones. These zones trigger alarms while the system is in the armed state and do not trigger alarms while the system is in the disarmed state. Other sensors are linked to 24-hour zones which trigger alarms irrespective of arming/disarming.

Arming while perimeter zones are not secured (doors and/or windows are open): Your display will read "NOT READY" if a protected door or window is open. You can find out which zone is "not ready" by clicking the ilok button. You can eliminate the problem by closing the door/window or by performing "Forced arming" (zone deactivation) if this option was enabled by the system installer. In case you intentionally choose to bypass a zone, leave the door or window open and arm the system (a voice message will announce that "Forced Arming" is under way - not applicable in PowerMaxComplete that does not have VOICE option).

Bypassed zones will not be protected during one arming period.

**Gaining access to 24-hour zones:** If you wish to access a sensor defined as a 24-hour zone without causing an alarm:

- Click again the display will read:
   USER SETTINGS.
- Click i OK
   the display will read: ENTER CODE
   \_.

Key your secret 4-digit **<User Code>** - the buzzer will play the "happy tune" (- - - —).

You have 4 minutes during which the 24-hour sensor can be opened and accessed. When the 4 minutes are up, the system will automatically revert to the normal mode.

**Canceling accidental alarms:** Upon alarm, the internal sounder is activated first for a limited period of time (set by the installer). Then the external siren starts and the event is reported to the central monitoring station. If you accidentally cause an alarm, you may simply disarm the system before the external siren starts - the alarm will not be reported.

If you cause an alarm accidentally and the external siren has already started - you can still disarm the system within a time limit set by the installer (1 to 15 minutes, as desired). If you manage to disarm on time, a **CANCEL ALARM** message will be automatically sent to the central monitoring station.

# Failing to exit before the exit delay expires:

If you exit the protected site after the exit delay expires (the exit delay beeps stop), the system will interpret this as if you just entered. The entry delay countdown will begin and the entry delay beeps will sound. To prevent an alarm, you must disarm the system before the entry delay expires.

Unauthorized entry took place while you were away: If you hear alarm sirens when you are about to re-enter the premises, and lights which should be off are on - an intruder may still be inside or another event may have occurred. Do not confront the intruder - remain outside and call the emergency services.

# INTRODUCTION

#### 1. Introduction

#### Overview

The PowerMaxComplete is a wireless alarm control system that provides protection against burglary, fire and tampering. In addition, it can be used to control a light or an electrical appliance within your household and/or to monitor the activity of disabled or elderly people left at home. Status information is presented visually and verbally, and in most cases a recorded voice prompts you to take correct action - not applicable in PowerMaxComplete that does not have VOICE option.

The PowerMaxComplete includes an optional partition feature. Partitioning allows you to have up to three independently controllable areas with different user codes assigned to each partition. A partition can be armed or disarmed regardless of the status of the other partitions within the system.

The PowerMaxComplete is governed by a control panel (Figure 1) designed to collect data from various sensors that are strategically located within and along the perimeter of the protected site (Figure 2).

In the **disarmed state**, the system provides you with visual and verbal status information, and initiates an alarm if smoke is detected or upon disturbance in a 24-hour zone (a zone which is active 24-hours a day). In the **armed state**, the system will initiate an alarm upon detection of disturbance in any one of the armed zones.

You will need a 4-digit security code to master the system (code 0000 is disallowed), and you can authorize 7 other persons to use the system by providing them with their own security codes. Moreover, you can obtain up to 8 multi-function keyring transmitters and proximity tags that will allow you and other users to easily control major functions.

Proximity tags enable authorized people to enter restricted areas. Presenting valid proximity tag, while the system is armed (and when partitioning is set to disabled), causes the system to disarm. Presenting valid proximity tag, while the system is disarmed, causes the system to be armed in AWAY (optional HOME) mode.

The system identifies a wide range of events - alarms, attempts to tamper with sensors and several types of trouble. Events are automatically reported via the public telephone network, GSM network (in digital form), or GPRS network to central monitoring stations and to private telephones (in plain language and/or SMS messages). The person receiving such a message is expected to investigate the event and act accordingly.




Figure 1. Control Panel with Covers Closed

**IMPORTANT!** All you need to know to secure your premises can be found in Chapter 2 of this manual. If you are not familiar with some of the terms used here, refer to **APPENDIX B** at the end of this guide.




Figure 2. System Configuration

# **System Features**

Your PowerMaxComplete offers a large number of unique features:

- 30 zones: Each protected zone is identified by number and by name (ask your installer to assign names to your zones).
- 3 Partitions (optional): One of the advantages of the PowerMaxComplete is its ability to divide the system into a maximum of 3 partitions. Each partition may be viewed as a separate security system, each of which can be armed and disarmed individually individually or altogether in one operation.
- Multiple arming modes: AWAY, HOME, AWAY-INSTANT, HOME-INSTANT, LATCHKEY and BYPASS.
- Liquid crystal display (LCD): Plain-language status information and prompts are displayed on the front panel in large, clear letters.
- Real-time clock: The present time is visible on the display.
- Various reporting destinations: Events are reported automatically to central monitoring stations, private telephones of your choice, and even by SMS if GSM is installed.

- Selective reporting: Your installer can determine what type of event will be reported to which destination.
- Latchkey mode: An automatic "Latchkey" message is sent to chosen telephones if the system is disarmed by a "latchkey" user (a junior family member, for instance).
- Spoken announcements and instructions (not applicable in PowerMaxComplete that does not have VOICE option): Status- dependent, prerecorded verbal messages are heard over the built-in loudspeaker (if the voice prompts are enabled - see chapter 7).
- Message exchange (not applicable in PowerMaxComplete that does not have VOICE option): Before leaving the premises, you may record a short verbal message for other users of the system who may arrive later. Upon arrival, you can listen to verbal messages left by others for you.
- Keypad and wireless control: Full control from the keypad; major functions can be carried out by pressing buttons on hand-held miniature transmitters.
- Access from remote telephones: You may access the PowerMaxComplete from a remote telephone and Arm/Disarm it or receive system status information.

# INTRODUCTION

**Note:** Remote operation is performed per partition, or per user code defined for a particular partition, when partition is enabled.

- Numerical keys serve as function keys: In the disarmed state, numerical keys are used to control various system functions. A simple icon on each key identifies the task of that key.
- PGM remote control: Gate control mechanisms, courtesy lights and various other devices can be switched on and off via a special PGM (programmable) output. Your installer will determine the control means, in accordance with your needs.

Note for PowerMaxComplete with Partition feature: The PGM outputs operate on the entire alarm system and not per partition, when partition is enabled.

- Data retrieval: You can obtain status information, trouble information and review memorized alarm events - visually and verbally.
- Looking after elderly, physically handicapped and infirm individuals: The system can be programmed to monitor activity within the protected area and send out an alert message if the person under surveillance remains still for too long.
- Distress calls: Miniature pushbutton transmitters dealt out to specific individuals may be used for sending emergency calls for help.
- Disarming under duress: If a user is forcibly compelled to disarm the system, he can use a special code that disarms the system apparently as usual, but sends a silent alarm to the central station (see chapter 2).

- System supervision: All wireless detectors and wireless commanders within the protected site send periodic supervision messages. If such a message is overdue, the PowerMaxComplete displays an 'inactivity' trouble message. Your installer can disable this feature if so desired.
- Battery supervision: You do not have to worry about 'dead' batteries. The PowerMaxComplete displays a 'Low Battery' message whenever a battery in a wireless device is found to be near the end of its useful life.

#### **Terms of the Trade**

Better understanding of your system is assured if you take time to read the definitions in **APPENDIX B** at the end of this manual. However, if this is not your first alarm system, then simply read on.

#### **Control Pushbuttons**

When the keypad cover is closed, as shown in Figure 1, only two pushbuttons are visible - the top panel controls:

| Key      | Task                                     |
|----------|--|
| <b>\</b> | Advance from item to item within a given |
|          | menu.                                    |
| iloк     | Review status messages one by one        |
|          | and also select a displayed option.      |

With the keypad uncovered (see Figure 3), the special-function keys are visible. The tasks of these keys are explained in the relevant sections of this guide.





Figure 3. Controls and Indicators

- \* May not be functional on all versions of PowerMaxComplete.
- \*\* The Mute Speaker button 7 is active only if the "Set Voice Option" function is enabled ("enable prompts" see user setting flow-chart, fig. 8).

#### **Multi-Function Transmitter**

Your system responds to signals sent by a 4-button (MCT- 234) or a 6-button two-way (MCT- 237) 'keyfob' transmitter, or by a two-way wireless keypad (MKP-150/151) or keyprox (MKP-160) - see figure 4.

The MCT-234 keyfob transmitter is used to control single or multiple predefined partition(s) only. The MCT-237 keyfob transmitter and the two-way wireless keypad can control a single or any combination up to 3 partitions.



A PANIC alarm can be initiated: through the MCT-234 keyfob, by pressing AWAY and HOME together for 2 sec.; through the MCT-237 keyfob, by pressing the AUX1 and AUX2 buttons for 2 sec.; through the MKP-150/151 keypad by pressing the # and \* buttons for 2 sec., and through the MKP-160 keypad

by pressing the and buttons for 2 sec. Pressing AWAY twice within 2 seconds initiates Latchkey arming, if enabled by the installer. The devices can be used for:

- A. Controlling a gate or another electrical device: Pressing the AUX button opens/closes an electrically-controlled gate, or controls a chosen electrical device.
- B. Arming the system in the INSTANT mode (without an entry delay): Pressing the AUX button immediately after arming, during exit delay, causes the system to be armed without an entry delay. This means that entering the protected premises via any zone will trigger an immediate alarm. You and other holders of keyfob transmitters will have no problem, because you can disarm the system before

- entering by pressing the DISARM ( $\mathbf{M}$ ) button on your transmitter before entry.
- C. Getting status information (Voice version only): Upon pressing the AUX button on your transmitter, the voice module announces the system status over the loudspeaker - not applicable in PowerMaxComplete that does not have VOICE option. When partition is enabled, the control panel announces the status of the partition to which the keyfob is enrolled.
- D. Skip Exit Delay: Pressing the AUX button will immediately cause the system to arm "instant".

# <u>Disarming by a keyfob whose battery voltage is</u> low (if enabled by the installer)

If you try to disarm the system with a keyfob whose battery voltage is low, a protest beep will be heard for 15 seconds. During this period you should press again the disarm button of the keyfob or control panel (for the control panel, user code is required) to disarm the system. If you perform this action during the 15 seconds period, the Low Bat message will be stored in the event log.

If the disarm button is not pressed again during the 15 seconds period, perform either of the following actions:

- A. Press AWAY twice to arm the system, otherwise the system will not be armed and an acknowledgement (from the user that he knows about the Low Bat) will not be stored in the event log.
- B. Press AWAY and then press disarm button, to acknowledge, otherwise the acknowledgement will not be stored in the event log.

#### **Voice Announcements**

(Not applicable in PowerMaxComplete that does not have VOICE option).

The pre-recorded voice announcements respond to your commands by announcing what the system is doing and by prompting you to perform certain actions. They also announce alarms, troubles and identify the source of each event.

The sounds you will hear while using the control panel are:

- Single beep, heard whenever a key is pressed
- Double beep, indicates automatic return to the normal operating mode (by timeout).
- Three beeps, indicates a trouble event
- Happy Tune (- - —), indicates successful completion of an operation.
- Sad Tune (——), indicates a wrong move or rejection

# INTRODUCTION

#### **Proximity Tags**

#### When Partition is Disabled

Your system responds to valid proximity tags enrolled to the system. The proximity tag enables you to perform a variety of functions without entering user code, for example, arming, disarming, reading the event log, etc. Whenever the user code is required, you can simply present a valid proximity tag and perform the desired operation without the need to key-in your user code.

#### When Partition is Enabled

When the system is disarmed, after presenting a valid proximity tag to the control panel, the message "<OK> for AWAY" is displayed. Now you can press the ilok button to immediately arm the control panel, or wait for 3 second for system automatic AWAY arming (the message "Please exit now" will be displayed). Presenting the proximity tag once again will DISARM the system.

Instead of pressing the ilok button (see above), you can press the button once / twice (the message "<OK> for HOME" / "<OK> for disarm" is displayed, accordingly) and then press the press ilok button for HOME arming / disarming.

The control panel transmits an RF signal. A valid proximity tag that is presented to the control panel transmits a coded RF signal back to the control unit.

# **Screen Saver Option**

The Screen Saver option (if enabled by the installer) causes that when no key is pressed during more than 30 seconds, the display is "PowerMax" and the LEDs do not light (to prevent an intruder to know the system status). The normal display returns after pressing the button followed by entering user code (Refresh by Code) or after pressing any key (Refresh by Key), as selected by the installer.

If **Refresh by Key** was selected, the first pressing of any key (except Fire and Emergency) causes normal display return and the second press performs the key function. Regarding the Fire and Emergency keys, the first key press causes normal display return and also performs the Fire/Emergency function.

# 2. Securing The Protected Site

#### **Security-Related Pushbuttons**

| Key        | Function   |  |
|------------|--|--|
| $\bigcirc$ | Arming when nobody is at home                          |  |
| 魚          | Arming when people remain at home                      |  |
| 0 13       | Canceling the entry delay upon arming ('AWAY-INSTANT') |  |
| ьſ         | Disarming the system and stopping alarms               |  |
| # 1        | Partition selection                                    |  |

#### **Partition selection process**

**IMPORTANT NOTE:** Partitioning refers only to purchased control panels that support the partitioning feature.

Access to any desired partition is achieved through the use of an individual code or proximity tag. It is not possible to access the INSTALLER MENU if one or more partitions are in the AWAY or HOME modes.

Before attempting to perform any operation on any given partition(s), it is necessary to perform the operations below which enable you to select the desired/allowed partition(s) using the individual code or proximity tag:

**PRESS** 

RESULTANT DISPLAY



SELECT PARTITION

Enter partition # (1 - 3)

PARTITION 1

**Note:** The "Sad Tune" will be heard when attempting to select a partition to which no sensors / peripherals were enrolled

# **Preparing to Arm**

Before arming, make sure that READY (\*) / P# RDY (\*\*) is displayed. This means that all zones (\*) / partitions (\*\*) are secured and you may arm the system (\*) / partition (\*\*) any way you choose.

- \* In non-partitioned system
- \*\* In partitioned system

When **non partitioned system** is not ready for arming (at least one zone is open) the display reads NOT READY TRBL (trouble), NOT READY MEM (memory), NOT READY MSG (message) or NOT READY BYPASS.

When **partitioned system** is not ready for arming (at least one partition zone is open), the display is N. RDY TRBL (trouble), N. RDY MEM (memory), N. RDY MSG (message) or N. RDY BYPASS.


If the system is not ready for arming, click it or review the numbers and names of all open zones / partitions, one by one.

It is highly recommended to fix the open zone(s), thus restoring the system to the state of "ready to arm". If you do not know how to do this, consult your installer.

IMPORTANT! All arming procedures below are based on the assumption that quick arming has been enabled by the installer. If quick arming is disabled, the PowerMaxComplete will prompt you to enter your security code before arming.

#### **Arming 'AWAY'**


If the system is **READY**, proceed as shown:



ARM indicator lights steadily during the armed state.

# **Arming 'HOME'**

If all perimeter zones are **READY**, and quick arming is allowed, proceed as shown:



ARM indicator flashes during the armed state.


# SECURING THE PROTECTED SITE

# Switching from 'HOME' to 'AWAY'

Do not disarm the system - just press . The response will be the same as in ARMING AWAY above. Vacate the premises before the exit delay expires.

# Switching from 'AWAY' to 'HOME'

Do not disarm the system - just press this operation reduces the security level, the PowerMaxComplete will ask you to key in your master user code or user code, thus making sure that you are an authorized user.




[Enter code] Move to interior zone ARMING HOME

↓ (Exit delay) ↓

ARM HOME HH:HH

ARM indicator flashes during the armed state.

If an alarm occurred while the system was armed in the AWAY mode, the display will respond differently:




ARM indicator flashes during the armed state.

# Arming 'Instant'


You may arm AWAY or HOME without an entry delay - any detection in any zone will trigger an immediate alarm.

If you wish to arm AWAY-INSTANT, proceed as follows.



ARM indicator lights during the armed state.

If you wish to arm HOME-INSTANT, proceed as follows:



ARM indicator flashes during the armed state.


## **Forced Arming**

Forced arming allows you to arm any system partition even though one zone or several zones are disturbed, and the NOT READY message is displayed.

Automatic forced arming only works if the installer allowed this option while programming your system. Disturbed zones will be bypassed - they will not be armed. The protected site will not have maximum protection.


**Note:** When forced arming is carried out, the buzzer "protests" by emitting a continuous tone during the exit delay until the last 10 seconds of the delay. You can silence this signal by pressing the arming button again.

When NOT READY is displayed, Forced arming "AWAY" is performed as follows:



ARM indicator lights during the armed state.

When NOT READY is displayed, Forced arming "HOME" is performed as follows:



ARM indicator flashes during the armed state.


# **SECURING THE PROTECTED SIT**

# **Arming in the Latchkey Mode**

This mode is useful for a parent at work who wants to be sure that his children have returned from school and have disarmed the system. Arming in the "latchkey" mode means that a special "latchkey" message will be sent out when the system is disarmed by a "latchkey user".

Latchkey users are holders of user codes 5 through 8 or users of Keyfob transmitters 5 through 8. The latchkey message is considered an alert and not an alarm, and is therefore sent to the private telephones programmed by the user as targets for alert messages.


Latchkey arming is possible only when you arm "AWAY". To arm in the Latchkey mode, proceed as follows:



ARM indicator lights during the armed state.

# **Initiating a Panic Alarm**

You can generate a panic alarm manually in the disarmed and armed states alike. If this feature has been enabled by the installer (consult your installation company to determine if it has been enabled). The sequence will be as shown:




**Note:** If you are using a key-ring transmitter, press both AWAY and HOME buttons simultaneously for 2

To stop the alarm, press and then key in your valid user code.

# **Initiating Fire Alarm**

(This function is disabled in ACPO compliant version). You can generate a fire alarm manually (depends on the purchased PowerMaxComplete version - see PowerMaxComplete door label) in disarmed & armed states, as follows:





valid user code.



To stop the alarm, press and then key in your

#### **Initiating Emergency Alarm**

You can generate an emergency alarm manually (depends on the purchased system version - see PowerMaxComplete door label) in the disarmed and armed states as follows:



#### **RESULTANT DISPLAY EMERGENCY** Then, if or when the system is in the disarmed state: READY HH:MM


To stop the alarm, press and then key in your valid user code.

# **Disarming and Stopping Alarms**

(This function is disabled in ACPO compliant version). Disarming the system stops the siren before it stops automatically, irrespective of whether the alarm was initiated in the armed or the disarmed state.


After disarming, different displays may appear, depending on the current status of the system:

A. Disarming - no events: After an uneventful armed term, the disarming operation will progress as shown:



ARM indicator extinguishes

B. Disarming after alarm, with all zones ready: If the zone that alarmed in the armed state is back to normal, the disarming operation will as shown:




ARM indicator extinguishes.

# **SECURING THE PROTECTED SITE**

To read the alarm memory, refer to Chapter 5. The "MEMORY" message will disappear only upon re-arming the system.

C. Disarming after an alarm, with one zone still disturbed: If the zone that alarmed in the armed state is still disturbed, the disarming operation will progress as shown:




ARM indicator extinguishes

To read the alarm memory, refer to Chapter 5. The "**MEMORY**" message will disappear only when you rearm the system.

If you do not know how to return the disturbed zone to normal, consult your installer.

D. Disarming with the system in a state of trouble:


If trouble is detected in the armed state, the
TROUBLE indicator on the front panel will light and
the disarming operation will progress as shown:



ARM indicator extinguishes and JJJ sounds once per minute,

To find out what kind of trouble is being sensed, see Chapter 5. The **TRBL** display will disappear, the **TROUBLE** indicator will extinguish and the trouble beeps will stop upon eliminating the cause for trouble.

E. Disarming after an alarm, with the system in a state of trouble: The TROUBLE indicator on the front panel will light. If the zone that alarmed while the system was in the armed state is back to normal, the disarming operation will progress as shown:



ARM indicator extinguishes and JJJ sounds once per minute.

To find out which zone alarmed and what kind of trouble is being sensed, see Chapter 5. The **TRBL** display will disappear, the **TROUBLE** indicator will extinguish and the trouble beeps will stop upon eliminating the cause for trouble. The **MEMORY** message will disappear only upon rearming the system.

F. Disarming under Duress. If you are forcibly compelled to disarm the system, enter the default duress code (2580) or another code set by the installer. Disarming will take place normally but a silent alarm will be transmitted to the central station.

#### Siren Behavior

**Continuously ON** when initiated by a burglar zone or a 24-hour zone, and when a user initiates a "panic alarm".

When initiated by a fire zone (smoke is detected) **ON - ON - ON - pause - ON - ON - pause - .......** and so on.

If there is nobody around to disarm the system upon alarm and a zone remains "open", the siren will sound for the time duration set by the installer - then will stop. The strobe light keeps flashing until the system is disarmed.

# 3. Speech And Sound Control

(In PowerMaxComplete that does not have VOICE option, the SPEECH and VOICE features are not applicable, only the CHIME feature is applicable).

# Speech & Sound Cont. Push-buttons

The sound and speech-related functions offered by the PowerMaxComplete are controlled with the keypad, as detailed in the following list.

# For PowerMaxComplete that includes the partition feature:

Sound and speech-related features only apply to the partition(s) where the control panel is present. An activity performed via the control panel from another partition will be displayed and the LED will light. The operation will be added to the log file but will not be heard over the control panel speaker.

| Key | Function   |  |  |
|-----|--|--|--|
| 1 🗠 | Increasing the loudness of spoken messages                               |  |  |
| 4 🗠 | Decreasing the loudness of spoken messages                               |  |  |
| 7 🔼 | Enabling / disabling the loudspeaker                                     |  |  |
| 2 🔊 | Recording a spoken message for other users of the alarm system           |  |  |
| 5   | Listening to a recorded message left by another user of the alarm system |  |  |
| 8 🛈 | Enabling / disabling the chime function in chime zones                   |  |  |

# **Adjusting the Speech Volume**

The following diagram shows how to increase the loudness by clicking the <1> key (assuming that the volume was at minimum to begin with).

| PRESS      | RESULTANT DISPLAY |
|------------|-------------------|
| 1 🗠        | VOLUME+ <b>□</b>  |
| 1 + 4      | = =               |
| 1 🗠        | VOLUME+ 🔳 📗       |
|            |                   |
| 1 🗠        | VOLUME+ 📗 📗 📗     |
|            |                   |
| 1    (max) | VOLUME+ 🔲 🔲 🔲     |
| ( ''-)     |                   |

The following diagram shows how to decrease the loudness with the <4> key (assuming that the volume was at maximum to begin with).

| PRESS     | RESULTANT DISPLAY |
|-----------|-------------------|
| 4 🗠 (max) | VOLUME-           |
| 4 🗠       | VOLUME-           |
| 4 🗠       | VOLUME-           |
| 4 🗠       | VOLUME- ■         |

#### Voice ON/OFF


You can switch spoken announcements on and off by alternate clicking of the <7> key, as shown below.

| <u>PRESS</u> | RESULTANT DISPLAY |
|--------------|-------------------|
| 7 🔼          | VOICE ON          |
| 7 <b>4</b>   | VOICE OFF         |
|              |                   |
|              | READY HH:MM       |

**Note:** The system will maintain the "Voice OFF" state until subsequent selection of "Voice ON'.

# **Message Exchange**


For message exchange you can record a verbal message for other users of the alarm system. Face the panel, press <2> and keep it pressed. When the display reads **TALK NOW**, start talking. The 5 dark boxes will slowly disappear one by one, from right to left, as shown in the diagram below.



Once the last of the boxes disappears, **RECORDING ENDED** will be displayed.

# SPEECH AND SOUND CONTROL

When you release the button, the display will revert to the normal status-displaying mode, but will also indicate that a message is waiting. For example:



To check your own message, listen to it within one minute from the end of recording (see Chapter 3 - Message Playback). This way the MSG indication will not be erased.


# **Message Playback**

To listen to a message left by another user of the system:

Click 5 and listen. PLAY will be displayed and the message will be played back over the built-in loudspeaker. When the playback ends, the display will revert to the normal status-displaying mode. If more than 1 minute elapsed after recording, the MSG indication will disappear.

#### **Chime ON/OFF**

You can disable / enable the chime zones by alternate clicking of the <8> key, as shown below:



CHIME indicator lights steadily when "chime on" is selected.

# 4. Electrical Appliance Control

#### **Control Options and Pushbuttons**

The system allows manual or automatic remote control of a device connected to the PGM output.

The user defines the ON and OFF times via the Scheduler (see Chapter 7 - Scheduler Function). The installer determines which zone sensors will switch the remote controlled appliances on and off. However, the decision whether the remote controlled appliance will respond as programmed is up to you (see next table).

| Key | Function   |
|-----|--|
| 3 📀 | Manual activation of A light or other household electrical appliance that is connected to PGM output.  |
| 6   | Manual deactivation of a light or other household electrical appliance that is connected to PGM output.  |
| 9 🕾 | Selecting the active automatic control method:  Sensors: The appliance is controlled by sensors (assigned by the installer for this).  Timer: The appliance is controlled by timer (ON and OFF times are defined by the installer).  Both: The appliance is controlled by sensors as well as by a timer. |

Examples of benefits gained by automatic remote control:

- Timer Control. When you are away, the timed activation / de-activation of an electrical appliance.
- **Zone Control.** Upon disturbance of a perimeter zone, the electrical device is switched on.

**Note**: Automatic activation and deactivation of electrical appliance depends also on the Scheduler setup (see Chapter 7 - Scheduler Function).

#### **Automatic ON/OFF Control**

You can select two of four options:

- By Timer ON
- By timer OFF
- By sensor ON
- By sensor OFF

The presently active options are shown with a dark box ( ) at the far right. To view the 2 other options click 9 .

A presently inactive option is shown without a dark box at the far right. The dark box will appear if you click ilok while the option is displayed. A "Happy Tune" indicates successful saving of a new option.

| PRESS                           | RESULTANT DISPLAY        |  |  |
|---------------------------------|--------------------------|--|--|
| 9 🗢                             | BY TIMER ON              |  |  |
|                                 | (If this is the default) |  |  |
| If not satisfied -              | BY TIMER OFF             |  |  |
| If satisfied -                  |                          |  |  |
| il <b>OK</b>                    | BY TIMER OFF             |  |  |
| iloK                            | BY TIMER OFF             |  |  |
| 9 🖎                             | BY SENSOR ON             |  |  |
|                                 | (If this is the default) |  |  |
| If not satisfied -<br>Press 9 🖎 | BY SENSOR OFF            |  |  |
| If satisfied -                  | BY SENSOR OFF []]        |  |  |
| i l OK                          | BY SENSOR OFF            |  |  |
| 9 🖎                             | READY HH:MM              |  |  |

# **READING ALARM MEMORY AND TROUBLE DATA**

# 5. Reading Alarm Memory And Trouble Data

#### **Reviewing Alarm/Tamper Memory**

The PowerMaxComplete retains in its memory alarm and "tamper" events that occurred during the last arming period.

For PowerMaxComplete that includes partition option: In order to review alarm and tamper events of a specific partition, you need to select the desired partition(s), (please refer to Partition Selection Process in Chapter 2).

**Note:** Alarms enter the memory only after expiry of the "abort period" (see **APPENDIX B**). This means that if you disarm the system immediately - before the abort period expires - there will be no memory indication.

#### A. Alarm / Tamper Indications


When the memory contains at least one event and the system is in the disarmed state, a flashing **MEMORY** message will be displayed as exemplified:

|           | READ     | ΣΥ        | HH:M    | М        |        |
|-----------|----------|-----------|---------|----------|--------|
|           | <b>(</b> | (alterna  | ting)   | 5        |        |
|           | REAL     | ΣΥ        | MEM     | ORY      |        |
| or, if tl | he syst  | tem is no | t ready | / for ar | ming - |
|           | NOT      | READY     | HI      | H:MM     |        |
|           | <b>(</b> | (alterna  | ting)   | 3        |        |
|           | NOT      | READY     | MEN     | /IORY    |        |

# **B. Investigating Alarm/Tamper Data**


To review memory content, click the iIOK button.

<u>EXAMPLE 1</u>: An alarm was triggered because the garage door - zone No. 12 - opened **but then reclosed**. In addition, the bedroom motion detector - zone No. 7 - sent a "Tamper" message because its cover had been removed.



In response to additional clicking of button, the display shows details of other events retained in memory (if any), or reverts to its initial state (see A above).

<u>EXAMPLE 2</u>: An alarm was triggered because the garage door - zone No. 12 - opened and **was left open**.



**Remember!** The memory indication and content are cleared upon the next arming of the system.

# Reviewing Trouble Information A. Trouble Indications

If TRBL flashes in the display, the TROUBLE indicator illuminates, and 3 beeps are sounded once per minute, you will have to investigate the system in order to find out the origin and type of trouble.

The LCD will display the device number(s) of the trouble indication. The trouble types are as follows:

# SENSOR / KEYFOB / WIRELESS COMMANDER TROUBLES

- Inactivity No radio signals have been received from a particular sensor / wireless commander (if its supervision feature has been enabled) during a pre-defined period.
- Low battery The battery in a sensor, keyfob or wireless commander is near the end of its useful life.
- "Clean me" The fire detector must be cleaned.
- Gas trouble Gas detector failure.
- Siren AC failure There is no power to the siren.

#### **GSM TROUBLES (if used)**

- GSM line fail GSM telephone line failure.
- GSM net fail GSM network failure.
- **RSSI low** The GSM received signal strength is low.
- GSM communication fail There is no communication (RS-232 format) between PowerMaxComplete and GSM unit.

#### SYSTEM TROUBLES

SYSTEM TROUBLES indicate the state of the entire system and not a specific partition.

# READING ALARM MEMORY AND TROUBLE DATA

- AC Supply Failure There is no power and the system is working on backup battery power (this trouble is reported 5 minutes after its occurrence).
- System Jammed A radio-frequency signal is blocking communication channel of sensors and control panel.
- Communication failure A message could not be sent to the central monitoring station or to a private telephone (or a message was sent but was not acknowledged).
- **CPU low battery** The backup battery within the control panel is weak and must be replaced (see Chapter 9 Replacing Backup Battery).
- CPU tamper The control panel is being tampered with.
- Fuse Trouble The siren fuse is burnt out.
- Line Failure There is a problem with the telephone line.

**IMPORTANT!** If the trouble beeps bother you, disarm the system again (even though it is already disarmed). This will cancel the trouble beeps for 4 hours.

#### **B.** Investigating Trouble Sources

In a state of trouble, a flashing **TRBL** message is displayed as shown in the following examples:

READY HH:MM

(alternating)

READY TRBL

or, if the system is not ready for arming 
NOT READY HH:MM


(alternating)

NOT READY TRBL

You can review the current troubles one by one, by clicking the I OK button.

<u>EXAMPLE</u>: The kitchen sensor - zone No. 9 - has been inactive and the living room sensor - zone No. 15 - has reported a low battery. However, these troubles do not prevent the system from being "ready to arm".

To investigate the source of trouble, proceed as follows:




In response to further clicking of it ok, the display will show details of other troubles (if any), or

will revert to the initial alternating displays (see example above).

# Reviewing Memory & Troubles at the Same Time

If alarms / tamper events are retained in the alarm memory and at the same time a state of **trouble** exists, the display will behave as shown below:



**Note** (not applicable to PowerMaxComplete that does not have VOICE feature): When a voice message is in memory, the **MSG** display will also appear (as shown in Chapter 3 - Recording a Message).

To read status information - memory data, open zones and trouble sources (in this order) - click the button repeatedly. The memory content will be displayed first, in the same manner shown in Chapter 5 - Reviewing Alarm / Tamper Memory. If the system is not ready, open zone information will follow in the same manner as shown in Chapter 2 - Preparing to Arm. Trouble sources will be displayed last, in the same manner shown in Chapter 5 - Reviewing Trouble Information.

# **Correcting Trouble Situations**

The trouble indications (illuminated TROUBLE indicator and flashing TRBL message) are cleared once you eliminate the cause for trouble. If you do not know how to cope with a trouble situation, report it to your installer and seek his advice.

**INACTIVITY**: Once an inactive sensor or wireless commander renews its periodical transmissions, the inactivity trouble no longer exists and will no longer be indicated by the control panel.

**LOW BATTERY:** Upon replacing the battery in a wireless device in a keyfob or in a wireless commander that reported a low battery, the next transmission made by the relevant sensor will include a "battery restored" message, and "low battery" will no longer be indicated by the control panel.

**SYSTEM TROUBLE**: Correction of any one of the system troubles is automatically sensed by the control panel, and the trouble indication is cleared accordingly.

# 6. Special Functions

#### **Looking after People Left at Home**

important characteristic the PowerMaxComplete is its ability to function in a mode contrary to the usual behavior of an alarm system. When the system is in the disarmed state (or even when armed "HOME" with perimeter protection only), it can keep track of in-house activity and will report lack of motion in interior zones if there is no detection of motion within predetermined time limits.

To use this characteristic, you must ask your installer to program a specific time limit beyond which lack of motion will be reported as a "not active" alert.

To make things clear, let us assume that an elderly, sick or handicapped person is left unattended in a protected site. This person, disabled or sick as he may be, will not stay entirely still for hours. It is only natural that even while being asleep he will turn over in his bed from time to time. He might also wander into the kitchen to eat or drink, or to the bathroom for other necessities. Upon doing so, the bedroom, bathroom and kitchen motion detectors will detect his movement.

If, for example, the "lack of motion" time limit is set by your installer to 6 hours, a virtual 6-hour clock will carry out a 6-hour "countdown".

If motion is detected within the 6-hour time frame, the countdown will restart from the beginning (the virtual 6-hour clock will be "reset") and no alert message will

If no motion is detected within the 6-hour time frame in any interior zone, the control panel will send a "not-active" alert message to the central monitoring station or to private telephones designated by the installer.

IMPORTANT! In addition, you may provide the person confined to interiors with a single-button transmitter for distress situations. paragraph.

# **Emergency Calls for Help**

Suppose the disabled person discussed above has an accident such as falling in the bathtub without being able to get up. It might take hours before the "No Active" alert is sent out, but he (or she) must be assisted much sooner.

Even though the odds for such an accident are not high, it is advisable to provide the disabled person with a miniature, single-button pendant-type or wristwatchtype transmitter. Pressing the button on this transmitter will cause the PowerMaxComplete to send an "emergency call" to the central monitoring station or to private telephones designated by the installer.

To make this possible, ask your installer to define one of the 28 zones of the PowerMaxComplete as an emergency zone.

Then, obtain one of the transmitters listed below and link this transmitter's ID code to the emergency zone.

Compatible distress transmitters are (see Fig. 5):

MCT-201 - pendant-type MCT-211 - wristwatch-type

MCT-101 - pocket-type

MCT-201



MCT-211 Figure 5. Single-button Emergency Transmitters

#### **Remote Control by Telephone**



# A. Establishing Telephone Communication

You can access the PowerMaxComplete system from a remote telephone and perform arming and disarming, activation and deactivation of electrical devices and the auxiliary output (PGM), record, playback and erase a voice message, and investigate the system status. The process is shown in the next illustration.

- 1. Dial the PowerMaxComplete tel. No.
- 2. Wait for 2-4 rings then hang up.
- Wait 12-30 sec.
- 4. Redial PowerMaxComplete tel. No. (Sound will be heard for 10 sec.).

Not applicable when dialing to the GSM number of the PowerMaxComple te. Proceed to step 5.

- 5. [\*] (to stop the sound) 1
- 6. [ser code], [#] <sup>2</sup>
- 7. Desired command, see next table 3

#### Notes

- (1) The PowerMaxComplete responds in a similar way if you just dial once and wait until you hear telephone rings (in USA, for example, 11 rings).
- (2) Entering of user code is required once only.
- (3) If you wait more that 50 seconds (may change according to setup / use) without keying a command, the PowerMaxComplete will disconnect the line.

#### **B. Executable Commands**

|    | Command   | Single Partition Keying<br>Sequence                              | All Partitions Keying Sequence / Partition Disable   |
|----|---|--|--|
| 1  | Disarming   | [★]→[1]→[#]  | [★]→[0]→[partition]→[1]→[#]  |
| 2  | Arming Home   | [★]→[2]→[#]  | [★]→[0]→[partition]→[2]→[#]  |
| 3  | Arming Home-Instant   | [★]→[2]→[1]→[#]  | [★]→[0]→[partition]→[2]→[1]→[#]  |
| 4  | Arming Away   | [★]→[3]→[#]  | [★]→[0]→[partition]→[3]→[#]  |
| 5  | Arming Away-Instant   | [★]→[3]→[1]→[#]  | [★]→[0]→[partition]→[3]→[1]→[#]  |
| 6  | Arming Away-Latchkey  | [★]→[4]→[#]  | [★]→[0]→[partition]→[4]→[#]  |
| 7  | Arming Away-Instant-Latchkey                                      | [★]→[4]→[1]→[#]  | $[\star] \rightarrow [0] \rightarrow [partition] \rightarrow [4] \rightarrow [1] \rightarrow [\#]$ |
| 8  | Review status of specific partition (Voice version only) (*)      |  | [★]→[0]→[partition]→[9]→[#]  |
| 9  | Activating PGM output   | [ <b>★</b> ] <b>→</b> [5] <b>→</b> [0] <b>→</b> [1] <b>→</b> [#] | [★]→[5]→[device No.]→[1] →[#]  |
| 10 | Deactivating PGM output   | [ <b>★</b> ] <b>→</b> [5] <b>→</b> [0] <b>→</b> [0] <b>→</b> [#] | [★]→[5]→[device No.]→[0] →[#]  |
| 11 | Two-way voice communication (Voice version only) (see sub-par. C) | [★]→[7]→[#]  | [★]→[7]→[#]  |
| 12 | Recorded message playback   | [★]→[8]→[1]→[#]  | [★]→[8]→[1]→[#]  |
| 13 | Recorded message start record                                     | [★]→[8]→[2]→[#]  | [★]→[8]→[2]→[#]  |
| 14 | Recorded message stop record                                      | [★]→[8]→[3] →[#]   | [★]→[8]→[3] →[#]   |
| 15 | Recorded message erase message                                    | [★]→[8]→[4]→[#]  | [★]→[8]→[4] →[#]   |
| 16 | Investigating system status (Voice version only)                  | [★]→[9]→[#]  | [★]→[9]→[#]  |
| 17 | Quit (end communication)  | [★]→[9]→[9]→[#]  | [★]→[9]→[9]→[#]  |

<sup>\*</sup> This command operates on ALL permitted partition(s).

#### C. Two-Way Voice Communication

Perform steps 1-6 in Establishing Telephone Communication above and continue as follows:

- 1. **□** [★]→[7]→[#]
- 2. Wait for 2 beeps
- 3. [3] or [1] or [6] (see below)

The system will start to function in the "LISTEN IN" mode, letting you hear the sounds within your residence for 50 seconds. If the person under surveillance happens to speak or cry then, you will hear this. You can switch the system to **Listen-In**, **Speak Out** or **Full Duplex**, as shown in the next table.

| Command  | Key |
|--|-----|
| Listen-in (listening to the person at home) (*)  | [3] |
| Speak-out (speaking to the person at home) (*)   | [1] |
| Full-duplex (listening & speaking) (*)   |     |
| <b>Note:</b> To prolong the communication session by 50 seconds, press [3], [1] or [6] again, as required. |     |

<sup>\*</sup> The 2-way communication can be terminated by anyone close to the PowerMaxComplete, by disarming the system.

#### Remark Regarding Listen-in & Speak-out modes

Listen-in & Speak-out modes allow one way speech at a time. Back and forth exchange of uninterrupted speech between two parties is a method normally used in military, commercial and amateur radio communication. Once you finish talking you should say "Go Ahead" or "Over" and then switch from speak-out to listen in. When the person at home finishes talking he should also say "Over", as a cue to you to switch back from Listen-in to speak out.

#### **EXAMPLE**:

You (at remote telephone): [3] [1], "Hey, George, can you hear me? Are you in any trouble? Over"....

Person at home: "Yes, I am. I had a dizzy spell while trying to get out of bed and fell on the floor. I am unable to get up and my thigh hurts. Can you help me? Over"...

You (at remote telephone): [1], "Sure, I will send someone right away, stay put - over". [3]. Person at home: "Thanks, please hurry, over".

You (at remote telephone): [3] [1], "All right, over and out"..... [3] [ $\star$ ] $\rightarrow$ 9] $\rightarrow$ [9] (END OF SESSION).

# SPECIAL FUNCTIONS

Important! If you wish to exit the two-way communication mode and execute another command, just press [\*] and then key your user code followed by the command (see "keying sequences" in Executable Commands table above).

# **Reporting to Private Telephone**

control panel

The PowerMaxComplete can be programmed by the installer for selective transmission of messages to private telephone subscribers. Messages are divided by type into 4 groups:

| Group | Events Reported   |
|-------|---|
| 1     | Fire (*), Burglary (**), Panic, Tamper                          |
| 2     | Arming AWAY, Arming HOME, Disarming                             |
| 3     | No-activity, Emergency (***), Latchkey, Gas, Flood, Temperature |
| 4     | Low-battery AC failure  |

**Note:** In control panel with no-voice option, the following siren signal will be sent to private telephone upon event reporting:

- \* FIRE: ON ON ON pause.... (--- ---....).
- \*\* BURGLAR: ON continuously (\_\_\_\_\_...
- \*\*\* EMERGENCY: 2-tone siren; like an ambulance. When the called party answers a call initiated by the PowerMaxComplete, he will hear a verbal message composed of the "house identity" and the type of event that occurred. For example, once smoke is detected in the Smith residence, the message will be: [The Smith Residence Fire Alarm].

If a person under surveillance in the Watkins residence has been inactive, the message will be:

[The Watkins Residence - No Activity].

The called party must acknowledge the message (as explained later on), but if he does not respond, the message will be transmitted repeatedly as many times as possible within a 45-second time limit. When the 45 seconds are up, the PowerMaxComplete will disengage the line and call the next private telephone number on its list.

The called party can acknowledge the message by pressing a key on the telephone keypad, as follows.

| Command   |  |  | Key |
|---|--|--|-----|
| Acknowledge PowerMaxComplete line and considers reported. |  |  | 2   |

| Command   | Key |
|---|-----|
| Acknowledge and listen-in: The protected site is "bugged" for sound for 50 seconds. The called party may prolong the listening session by pressing [3] again before the PowerMaxComplete disengages the line, or by pressing [1] to speak.                          | 3   |
| Acknowledge and speak out: The called party may speak for 50 seconds to whoever is in the protected site. The called party may prolong the "speak out" session by pressing [1] again before the PowerMaxComplete disengages the line, or by pressing [3] to listen. | 1   |
| Acknowledge and 2-way conversation: You and the called party can speak and listen without any necessity to switch the system from "listen-in" to "speak-out" and vice versa for 50 sec. (extendable).   | 6   |
| Acknowledge and request a status report: The PowerMaxComplete will issue a verbal report of system status. For example: [Disarm - ready to arm] or [Disarm - back door open] or [Disarm - alarm in memory].   | 9   |

# Remote Control by SMS

PowerMaxComplete system with an optional internal GSM unit can respond to SMS commands from any cellular GSM telephone, only if the "REM ACCESS ON" command was pre-selected by the system installer.

The various SMS commands are detailed in the following table (the detailed SMS message sending process is described in the cellular telephone user's guide). In this table, "<code>" means 4-digit user code and blank space simply means blank space.

#### **SMS Command List**

In the following table, "P#" is used only for PowerMaxComplete with partition enabled - use P1, P2, P3, or P4, according to the partition number.

|    | Command                                 | Individual Partition SMS Format  | All Partitions SMS format /<br>Partition Disable   |
|----|---|--|--|
| 1  | Arm AWAY                                | "AWAY <code>"<br/>or<br/>"AW <code>"</code></code>   | "P# AWAY <code>"<br/>or<br/>"P# AW <code>"</code></code>   |
| 2  | Arm AWAY instant                        | "AWAY INST <code>" or "AWI <code>"</code></code>   | "P# AWAY INST <code>"<br/>or<br/>"P# AWI <code>"</code></code>                                     |
| 3  | Arm AWAY Latchkey                       | "LATCHKEY <code>"<br/>or<br/>"LK <code>"</code></code>                                       | "P# LATCHKEY <code>"<br/>or<br/>"P# LK <code>"</code></code>                                       |
| 4  | Arm AWAY Latchkey instant               | "LATCHKEY INST <code>"<br/>or<br/>"LKI <code>"</code></code>                                 | "P# LATCHKEY INST <code>"<br/>or<br/>"P# LKI <code>"</code></code>                                 |
| 5  | Arm HOME                                | "HOME <code>"<br/>or<br/>"HM <code>"</code></code>   | "P# HOME <code>"<br/>or<br/>"P# HM <code>"</code></code>   |
| 6  | Arm HOME instant                        | "HOME INST <code>"<br/>or<br/>"HMI <code>"</code></code>                                     | "P# HOME INST <code>"<br/>or<br/>"P# HMI <code>"</code></code>                                     |
| 7  | Disarm                                  | "DISARM <code>"<br/>or<br/>"DA <code>"</code></code>   | "P# DISARM <code>"<br/>or<br/>"P# DA <code>"</code></code>   |
| 8  | Turn PGM on                             | "PGM ON <code>"</code>   | "P# PGM ON <code>"</code>  |
| 9  | Turn PGM off                            | "PGM OFF <code>"</code>  | "P# PGM OFF <code>"</code>   |
| 10 | Define custom house identity (see note) | "HOUSE NAME <code> <house id="">" or "HN <code> <house id="">"</house></code></house></code> | "P# HOUSE NAME <code> <house id="">" or "P# HN <code> <house id="">"</house></code></house></code> |
| 11 | Query system status                     | "STATUS <code>"<br/>or<br/>"ST <code>"</code></code>   | "P# STATUS <code>"<br/>Or<br/>"P# ST <code>"</code></code>   |

Note: House ID includes up to 16 characters, for example JOHN'S HOUSE.

#### Reporting by SMS

This option is applicable only if the GSM Module is installed. The PowerMaxComplete system can send SMS messages to a registered SMS telephones (up to 4). (The SMS telephone registration is preselected by the system installer).

The reported SMS messages are quite clear and selfexplanatory and therefore are not detailed in this guide.

Example of the reported SMS messages:

- JOHN'S HOME\*\*AWAY\*\*
- JOHN'S HOME \*\*DISARM\*\*
- JOHN'S HOUSE POWERMAX: LOW BATTERY GARAGE: LOW BATTERY
- JOHN'S HOUSE STATUS MESSAGE 01 (Event list is displayed)

#### Note

Status messages can be sent only to a calling telephone whose identity number is not blocked by the user!

**Note:** The PowerMaxComplete may react with a delay to received SMS messages if a GPRS session is in progress at the same time.

# **Conducting a Walk Test**

The walk-test is an indispensable operation by which you verify that all detectors function properly, without disturbing the neighbors with loud sirens. The test must be performed **at least once a week**, and should include all detectors in all zones.

Before performing walk-test, all the detectors must be in normal state. Normal state is achieved when no motion is made for at least 2 minutes.

# **SPECIAL FUNCTIONS**

**Note:** During the test period, 24-hour zones will not cause an alarm if violated, but a fire zone will function normally.

A typical test will take place as follows:

A. Click The display will read:

WALK TEST

**B.** Click the ilok button, the display will prompt you for your user code:

ENTER CODE ....


**C.** Enter your master user code. The siren will sound for 2 seconds and the display will change to:

TESTING

D. Walk throughout the protected area and make sure you trigger every detector with no exception (move across the field of view of motion detectors and open/close doors and windows). Each time a detector is triggered:

- The "Happy Tune" will sound,
- The zone name and number will be displayed briefly.


**EXAMPLE 1:** You triggered a **motion detector** in the living room (zone 11). The display will show:




After 5 seconds the display will revert to:

TESTING

**EXAMPLE 2:** You opened a **window** in partition 3 in the guest room (zone 13). The display will show:



E. When done, click the ilok button repeatedly. The display will show the test results, partition after partition and zone after zone, in ascending numerical order. For example:



or: "Z13 NOT OK" if there was no response from Z13.

F. To resume testing, click . To quit the test mode, click . The display will then read:

<OK> TO EXIT

G. Click i OK. The display will revert to its normal state.

# 7. User Settings

#### What are the Settings You Need?

The installer provides you a ready-to-use alarm system, but a few settings and adjustments will still be needed.

**Note:** Although the user settings are your responsibility, you may request your installer to perform them for you (except for the user codes, which you would like to keep secret).

The user settings include (if enabled by the installer):

- Bypassing zones determining which zones will be bypassed (disabled) during the present disarm period and the next armed period.
- Reviewing the bypass list "show bypass" displaying the numbers and names of bypassed zone one by one.
- Recalling the last bypassing scheme\*\* "recall bypass" re-using the previous bypassing
   scheme, which becomes suspended after
   disarming but is still saved in the
   PowerMaxComplete memory.

**Note:** RECALL BYPASS is applicable when partition is disabled.

- Private report\* determining the event groups to be reported to private telephone subscribers. Determining the 1<sup>st</sup>, 2<sup>nd</sup>, 3<sup>rd</sup> and 4<sup>th</sup> telephone numbers to which the system will report event messages that were defined by the system installer. Determining the number of times the called party's private telephone number is dialed. Determining whether or not 2-way voice communication with private telephones will be allowed. Determining whether to use a single acknowledge signal, or, an acknowledge signal from each telephone before the current event is considered reported. Determining the 1<sup>st</sup>, 2<sup>nd</sup>, 3<sup>rd</sup> and 4<sup>th</sup> SMS telephone numbers to which preselected event types will be reported.
- Setting user codes\* programming a security code for yourself and additional 7 codes for other system users. Codes 5 through 8 are "Latchkey" user codes (see Chapter 2 - Arming in the Latchkey Mode for additional details).
- Enrolling keyfob transmitters\* teaching the PowerMaxComplete system to recognize the ID code of each keyfob transmitter (multi-button, Code-Secure™ type, wireless transmitter), so that the PowerMaxComplete can respond to commands transmitted by them.
- Enrolling proximity tags Teaching the PowerMaxComplete to recognize the ID of each proximity tag so that the PowerMaxComplete can respond to proximity tags presentation.

- Setting voice options\* (not applicable in PowerMaxComplete that does not have VOICE feature) - Enabling or disabling verbal announcements (prompts).
- Auto arm option\* enabling or disabling automatic arming (at a predefined time).
- Setting auto arm time selecting automatic arming time.
- Using squawk option\* enabling/disabling LOW/MID/HI squawk (short siren sound) upon arming and disarming. All the options are applicable for wireless siren. For wired siren, refer to LOW, MID and HI options as "squawk enable".
- Setting the time and time format\* adjusting the built-in clock to show the correct time and time format.
- Setting the date and date format\* adjusting the built-in calendar date and date format.
- Setting the scheduler\* setting schedule for devices start/stop activation.
- \* This option can be accessed only if master user code has been entered.
- \*\* This menu is not available when Partition is enabled.

#### **Entering the User Settings Menu**

Figure 7 describes how to enter User Settings menu (when all zones/partitions are secured).

Click the keys that you are instructed to press. The resultant display is shown below each instruction




Figure 7 - Entering User Settings Menu

The next paragraphs include User Settings instructions, step-by-step. However, if you want to get an overall view of the entire User Settings menu, refer to figure 8 - User Setting flow-chart. You can use the flow chart as your only guide along the user settings process, instead of going through the step-by-step instructions.

# **Bypassing Zones**

#### A. General Guidance

You can program the PowerMaxComplete to exclude (bypass) selected zones, regardless of whether these zones are "functional" (undisturbed) or "open" (disturbed). Bypassing permits free movement of people within certain zones although the system is armed. It is also used to temporarily remove from service faulty zones that require repair work. Fire and temperature zones can not be bypassed.

Remember – zone bypassing compromises security!

**Note:** Zones will be bypassed throughout <u>one</u> <u>disarm-arm period only.</u> Disarming the system after arming will suspend the entire bypassing scheme, which can be recalled later, if so desired.

#### B. Bypassing Procedure

When partition is enabled, you may set the bypass option according to the type of partition access permission.


Having entered your <u>user code</u> successfully (see above - Entering to the User Settings Menu), the display will read:

SET BYPASS

If at this point you click it ok, the number, state and name of the first zone / partition containing the first zone (in PowerMaxComplete with partition feature) will be automatically displayed. Three states are possible:

- Open: The zone is not secured you can bypass it if you do not wish or know how to solve the problem just now.
- Bypassed: The zone is presently bypassed (you bypassed it before but haven't armed the system yet).
- **Functional:** If there is nothing wrong with the zone, its state is described as "Functional".

Let us assume that Zone 1 is "open" and you wish to bypass it, and the rest of the zones are functional.



You can select any other item on the USER SETTINGS

menu or quit programming by clicking . When <**OK**> **TO EXIT** is displayed - click . When .

After end of bypassing operation, **BYPASS** blinks:

READY BYPASS or NOT READY BYPASS


This indication will persist as long as the system remains disarmed, and will disappear once the system is armed.

**Note: BYPASS** will alternate in the display with other messages, like: **Trouble, Memory** and **Message**.

#### C. "Unbypass" Procedure

Suppose you wish to restore a zone to service after having completed the bypassing scheme. Simply reenter the SET BYPASS menu (see <u>Bypassing</u>

Procedure above), and click or until the zone you wish to "unbypass" is on display. Refer to the following steps.



item on the USER SETTINGS menu, or click to quit programming. When **<OK> TO EXIT** appears - click ilok

# **Reviewing the Bypassed Zone List**

Having entered your <u>user code</u> successfully (see above - Entering to the User Settings Menu), the display will read:

SET BYPASS

Click to change the display into:

SHOW BYPASS

Click to change the display into:

BYPASS LIST

If at this point you click it OK, the number, state and name of the first **bypassed** zone will be displayed.

You can now click review all bypassed zones, in ascending numerical order. When done, clicking will get you back to SHOW BYPASS and clicking will get you back to <OK> TO EXIT.

# **Recalling the Last Bypass Scheme**

Arming the alarm system with several zones in the bypassed state is in fact "partial arming". An identical partial arming may be repeated by recalling the last bypassing scheme (that was suspended and memorized upon disarming the system).


Having entered your <u>user code</u> successfully (see above - Entering to the User Settings Menu), the display will read:

SET BYPASS

Click twice to change the display into:

RECALL BYPASS

At this point proceed as follows:



You may now select any other item on the USER SETTINGS menu or quit programming by clicking

. When <OK> TO EXIT is displayed - click

I OK

.

# **Programming Private Report**

Having entered your Master User Code successfully (see above - Entering the User Settings Menu), click button repeatedly (if necessary) until the display will read:

REPORT TO PRVT

#### Report to Private

Here you determine the event groups to be reported – "disable report", "all", "all (-op/cl)" (all messages, except open/close), all (-alerts) (all messages, except alerts), "alarms", "alerts", "op/cl" (open/close).

#### **Private Telephone Numbers**

Here you determine the 1st, 2nd, 3rd and 4th telephone numbers to which the system will report event messages that were defined by the system installer.

#### **Redial Attempts**

Determining the number of times the called party's private telephone number is dialed (1, 2, 3, or 4 attempts).

#### Voice Private

Here you determine whether or not 2-way voice communication with private telephones will be allowed.

#### **Telephone Acknowledgement**

Here you determine whether to use a single acknowledge signal, or, an acknowledge signal from each telephone before the current event is considered reported.

#### **SMS Messages**

Here you determine the 1st, 2nd, 3rd and 4th SMS telephone numbers to which pre-selected event types will be reported.

Perform the above mentioned settings according to Figure 8 (Private Report) menu. These settings may be performed by the installer, if desired.

You may now switch to any other item on the USER SETTINGS menu or quit programming by clicking until <OK> TO EXIT is displayed and then clicking I OK

#### **Setting the User Codes**

A maximum of eight 4-digit codes can be defined out of a total of  $(10)^4 = 10000$  user code possibilities. Having entered your <u>Master User Code</u> successfully (see above - Entering the User Settings Menu), click until the display reads:

SET USER CODES

**User Code 1** replaces the factory default master user code, and should be assigned to the master user of the system. This code can not be erased.

**User Codes 2, 3** and **4** can be assigned to additional users - family members, co-workers etc.


**Codes 5 through 8** are assigned to "Latchkey Users" (see Chapter 2 - Arming in the Latchkey Mode, for an explanation of the latchkey mode).

CAUTION! Code "0000" is not valid! Do not use it.

**Note:** The duress code set by the installer (2580 by default) cannot be selected as a normal user code. Any attempt to program it will be rejected by the PowerMaxComplete.

Master user code is valid for all 3 system partitions. When partition is enabled, user codes 2 -8 are valid for predefined partitions only


To program the codes, proceed as follows:




You may now select any other item on the USER SETTINGS menu or quit programming by clicking

. When <OK> TO EXIT is displayed - click

ilok
.





Notes:

- (1) Functions inside black rectangles are accessible only if master user code was entered.
- (2) For the year, enter the two last digits only.
- (3) Press I to display the number, state and name of first bypassed zone. Press repeatedly to view all the bypassed zones.
- (4) To enter "A" (AM) press 🕯 🛭 (or one of the 3 keys above it), to enter "P" (PM) press 🛮 🔼 (or one of the 3 keys above it).
- (5) SET/SHOW/RECALL BYPASS menus are accessible only if "manual bypass has been selected by the installer.
- (6) Applicable in PowerMaxComplete that has VOICE feature In the SET VOICE OPTION, if you select "enable prompts", the Control Panel mute speaker button 

  ▼ is active.

Figure 8 - Users Settings Flow Chart




Figure 8 DETAIL "A" - Scheduler Function

# **Enrolling Keyfob Transmitters**

Keyfob transmitters are multi-button wireless units of the CodeSecure™ type with up to 16 million ID codes combinations. Eight system users carry keyfob transmitters to exercise better, quicker and safer system functions control. Your control panel must recognize the unique identification code (ID) of each such keyfob to respond to commands transmitted by them.

Before anything else, gather up all keyfob units you intend to enroll, and make sure they all have batteries installed

Keyfob transmitter enrolling involves the following steps:

your Code A. Having entered Master User successfully (see above - Entering the User Settings Menu), Click the ▶ button (repeatedly, if necessary) until the display will read:

ENROLL KEYFOB

B. Click . The display will read:

KEYFOB No:

C. Suppose that the Keyfob you are about to enroll is to be designated as Keyfob No. 5. Assuming that memory location No. 5 is free - no keyfob has vet been enrolled to it - click the <5> kev. The display will change to:

KEYFOB No: 5

The clear space at the far right tells you that the memory location is free.

D. Click itok. The display will prompt you to initiate a transmission from the chosen keyfob:

TRANSMIT NOW

**E.** Initiate a transmission from the chosen keyfob by pressing any one of its pushbuttons. In response, the "Happy Tune" (- - - - - will sound. When partition is disabled, the display will read:

KEYFOB No: 5 

Proceed to step "I" below. When partition is enabled, the display will read:

**ACCESS TO PART** F. Click F01: P1 P2 P3

G. Select the desired partitions via pushbuttons 1, 2 and 3 on the control panel keypad.

H. Click **і І ок** Л. The display will read: 5 KEYFOB No:

A dark box will appear at the far right, indicating that the chosen Keyfob has been enrolled as Keyfob No. 5.

I. From this point on, you may continue in several different directions:

If you wish to enroll another keyfob, select the desired number by:

- Clicking  $\$  to go up  $(6\rightarrow 7\rightarrow 8....)$ 

- Clicking  $\circlearrowleft$  to go down  $(4\rightarrow 3\rightarrow 2....)$ 

- Clicking → <keyfob #>.

To return to the main menu, click . This will bring back the display:

<OK> TO EXIT

You may now review and select any other mode on the User menu (by clicking <u></u>

#### **Deleting Keyfob Transmitters**

Occupied keyfob memory locations must be cleared (enrolled ID must be deleted) before enrolling a new ID. To delete an existing ID, proceed as follows:

A. Select the desired memory location, as described in the previous paragraph, steps A-C. If, for example, you selected keyfob No. 5, the display will read:

Kevfob No. 5 B. Click i I OK . The display will change to: <OFF> to delete C. Click . The display will change to: Keyfob No.

Note that the dark box at the far right has disappeared. It is now possible to enroll a new ID. It is also possible to leave the cleared keyfob location free and simply exit to the main menu.

# **Enrolling Proximity Tags (optional)**

When partition is enabled: Each proximity tag assigned to a partition will function as determined in "Setting the User Codes". Therefore, each proximity tag must be assigned a relevant user code. For example, proximity tag 3 is assigned to user code 3. Up to 8 proximity tags can be enrolled to the PowerMaxComplete control panel.

Proximity tag enrolling involves the following steps:

your Master User Code entered successfully (see Entering the User Settings Click the Menu). button (repeatedly, if necessary) until the display will read:

ENROLL PROX TAG B. Click i l ok The display will read: No: Tag

I OK . The display will prompt you to initiate a transmission from the chosen tag:

> PRESENT TAG

D. Present the tag to the control panel left bottom side. In response, the "Happy Tune" (- - - —) will sound and the display will change to:



A dark box will appear at the far right, indicating that the chosen tag has been enrolled.

- E. Click and enroll the next proximity tag (2, 3,...8), as described in step D.
- F. From this point on, you may continue in several different directions:
  - If you wish to enroll another tag, select the desired number by:
    - Clicking  $\longrightarrow$  to go up  $(6 \rightarrow 7 \rightarrow 8....)$
    - Clicking to go down  $(4\rightarrow 3\rightarrow 2....)$ - Clicking  $\rightarrow$  <tag#>.

ΤО

To return to the main menu, click . Thi will bring back the display:


EXIT

#### **Deleting Proximity Tags**

<0K>

Proximity tag memory locations must be cleared (enrolled ID must be deleted) before enrolling a new ID. To delete an existing ID, proceed as follows:

A. Select the desired memory location, as described in the previous paragraph, steps A-C. If, for example, you selected **Tag No. 5**, the display will read:



Note that the dark box at the far right has disappeared. It is now possible to enroll a new ID. It is also possible to leave the cleared zone or memory location free and simply exit to the main menu.

# **Setting the Voice Options**

(Not applicable in PowerMaxComplete that does not have VOICE option)

**Remember:** Voice prompts are heard over the builtin loudspeaker subject to two conditions:

- The voice option is enabled as shown below
- The loudspeaker is enabled by pressing the "7" key (see Chapter 3 - Voice ON-OFF)

Here you may select one of two options:

Enable prompts: Voice announcements

Disable prompts: No voice announcements


The presently programmed option will be shown, with a dark selection box ( ) at the far right of the display. You may view the other option (that does not have a dark box at the far right) by clicking . A dark box will appear if you click while the other option is displayed.

To set the voice option, proceed as follows:

Having entered your Master User Code successfully (see above - Entering the User Settings Menu), click the button until the display reads:

SET VOICE OPTIONS

From here, proceed as follows:



You may now select any other item on the USER SETTINGS menu or quit programming by clicking

. When <OK> TO EXIT is displayed - click

I OK

.


**Note:** When using the Model MCT-234 keyfob with the PowerMaxComplete, the voice prompts must be enabled.

# **Automatic Arming Option**

You can determine that the system will be automatically armed at any desired time.

Having entered master user code successfully, click until AUTO ARM OPTION is displayed.

From here, proceed as follows:




You may now select any other item on USERS SETTINGS menu or quit programming process by clicking . When "<OK> TO EXIT" is displayed, click I OK.

# **Setting Arming Time**

Having entered your Master User Code successfully (see above - Entering the User Settings Menu), click button (repeatedly, if necessary) until the display will read:

AUTO ARM TIME

From here, proceed as follows:



#### Notes:

- For 12h/24h time format selection, refer to Setting Time and Time Format below.
- Press "★" to enter A (AM), or press "#" to enter P (PM).


# **Enabling the Squawk Option**

You can determine that the system will activate (or not activate) high/mid/low wireless siren sound, for a short time, upon arming (1 beep) and disarming (2 beeps), by keyfob only.


Having entered your <u>Master User Code</u> successfully (see above - Entering the User Settings Menu), click the button (repeatedly, if necessary) until the display will read:

SQUAWK OPTION

From here, proceed as follows:



If not satisfied \_\_\_\_\_



For wireless siren, refer to "low", "mid" and "hi" options as "squawk enable".


You may now select any other item on the USERS SETTINGS menu or quit the programming process by clicking . When "<OK> TO EXIT" is displayed, click i OK.

# **Setting Time and Time Format**

Having entered your Master User Code successfully (see Entering the User Settings Menu, above), click until the display reads:


SET TIME&FORMAT

A. If 12h format is desired, continue as follows:



Note: To enter "A" - press [\*] or to enter "P" - press [#].

B. If 24h format is desired, continue as follows:




You may now select any other item on the USER SETTINGS menu or quit programming by clicking

. When <OK> TO EXIT is displayed - click

## **Setting the Date and Date Format**

Having entered your Master User Code successfully (see above - Entering the User Settings Menu), click button (repeatedly, if necessary) until the display will read SET DATE&FORMAT.

From here, proceed as follows:



You may now select any other item on the USER SETTINGS menu or quit programming by clicking

. When <OK> TO EXIT is displayed - click

i∃oĸ

#### Scheduler Function

The Scheduler enables to start and stop activity of the desired devices. You can select the day (Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, or daily) and then select the scheduled activity start/stop of the desired device. The process is demonstrated in "figure 8 DETAIL A".

#### **Installer Mode**

If the feature USER PERMIT was enabled by the system installer, the installer will be able to access the INSTALLER MODE only by using this menu, meaning that the INSTALLER MODE (described in the installer guide) can be accessed only with user permission (by using the user code).

# 8. Reading The Event Log

#### **Event Log Description**

All events are memorized in an event log. You can access this log, review the events one by one and draw functional conclusions.

If the event log fills up completely it continues to accept new events at the expense of old events - the oldest event is deleted upon registration of each new event.

The date and time of occurrence are memorized for each event. When reading the event log, events are shown in chronological order - from the newest to the oldest.

Because of the limited display space, the event description is shown first, then the date and time. The two displays are shown alternately several times, until you click i OK to move on to an older event, or until the "no action" 4-minute timeout restores the system to the normal operating mode.

Access to the event log is provided by clicking the asterisk (\*) key and then keying your master user code.

Should you wish to get an overall view of using the log, refer to Figure 9. The flow chart may even serve as your only guide to using the event log, instead of going through the written step-by-step procedure.




Figure 9. Using the Event Log

# **Reading Procedure**

To read the event log, proceed as follows:

A. While the system is in the normal operating mode, click the asterisk (★) key. The display will change to:


ENTER CODE \_ \_ \_ \_

B. Enter the current master user code. If the code is correct, the "Happy Tune" will sound and the display will read:

#### LIST OF EVENTS

**Important!** Entering an incorrect code 5 times in a row will initiate a 30-second penalty lockout of the keypad.

C. Click I OK. The latest event will be shown. Suppose that the latest event was an alarm in zone 13. The display will now read (when partition is enabled and the event is linked to a particular partition):



The two displays will be shown alternately until you click again to move to the next event, or until the event log times out (4 minutes).

**D.** Click i OK as many times as necessary to read all the data you need.



To guit the event log:

- Click or from anywhere within the log. The display will read:

Click i OK. The system will return to the normal operating mode.

#### 9. Maintenance

#### Replacing the Backup Battery

The PowerMaxComplete uses regular electrical supply, but incorporates backup 9.6V battery pack (see sticker on battery cover). It is important to replace it immediately upon receiving the following trouble message when reviewing system troubles (see Chapter 5 - Reviewing Trouble Information):

CPU LOW BATTERY

Front unit

Battery cable

Figure 10. Battery Replacement

Open battery compartment cover. Insert 6-battery pack or 8-battery pack and connect its connector to the PowerMaxComplete receptacle.

**Note:** Dispose of used backup batteries according to the manufacturer's instructions.

Note: Removal of the cover will start a "tamper" alarmthe trouble indicator will light and both "memory" and
"trouble" will flash in the display window. If you
interrogate the system at this stage by clicking the
ilok button, "CPU TAMPER ALARM" and
"CPU TAMPER OPEN" will be displayed, in addition to

With correctly inserted fresh batteries and tight closure of the lid, the TROUBLE indicator should extinguish. The "MEMORY" message will continue blinking in the display (caused by the "tamper" alarm you triggered). Clear it by arming the system and disarming it as soon as the exit delay starts.

# Replacing Wireless Devices Batteries

The **wireless sensors** supplied with your system are powered by high-capacity lithium batteries that last several years, depending on the number of times the sensor is triggered into transmission.

However, if and when a battery becomes weak, the sensor itself sends a "low battery" message to the control panel, and a low battery trouble message is displayed together with the zone information (see Chapter 5 - Reviewing Trouble Information).

The **keyfob transmitters** used to control the system are powered by an alkaline battery that lasts about one year if you do not press a button more than 10 times a day. Battery exhaustion is clearly evident by flashing of the transmitter's red indicator while the button is pressed (instead of lighting steadily).

When a low battery indication appears for the first time, it may be considered as a pre-warning. It normally gives you ample time (about 30 days) to obtain a new battery and replace the old one, and the detector or keyfob unit will be fully operational throughout this period. However, to be on the safe side, it is advisable not to wait that long.

Use the battery specified in the detector's own installation instructions. If you do not have the instructions, seek the advice of your installer or ask him to replace the battery in the specific device that sent the low battery message.

The **Wireless Commander** is powered by a long life 3 V Lithium battery. If the battery is weak when reading the PowerMaxComplete event log the display will read, for example, "C01 Low Battery" (meaning there is a low battery condition in the wireless commander #01), and the message "remote commander" will be heard.

For replacing the wireless commander battery, refer to the MCM-140+ Wireless Commander user guide.

After battery replacement, the detector unit will send a "battery restored" signal to the control panel, and the "low battery" message will be cleared.

"CPU LOW BATTERY".

# **Periodic Testing**

The components of your security system are designed to be maintenance-free as much as possible. Nevertheless, it is mandatory to perform a "walk test" at least once a week and after an alarm event to verify that all system detectors function properly. Proceed as described in Chapter 6 - Conducting a Walk-Test, and If there is any problem, notify your installer at once.

#### **Cleaning the Control Panel**

The control panel may occasionally get stained if touched with greasy fingers, and may accumulate dust after a long period of use. Clean it only with a soft cloth or sponge moistened lightly with a mixture of water and mild detergent, and then wipe it dry.

The use of abrasives of any kind is strictly forbidden. Also never use solvents such as kerosene, acetone or thinner. These will certainly ruin the external finish and damage the transparency of the top window.

# **PERFORMANCE LIMIT**

#### 10. Performance Limits

Although the alarm control system you purchased is highly reliable, it does not guarantee protection from burglary and fire hazards. Even the most advanced systems can be defeated or might occasionally fail to warn. Some of the reasons for this are:

**Sloppy maintenance:** If the system is used over a long period of time without testing, a key element such as a detector or a siren might go wrong without any visible or audible signs of failure. If a low battery warning is neglected, there will be no backup power to keep the system operational during a power outage.

**Power failures:** In case of prolonged absence from the protected site, the mains supply may suddenly fail (an earth leakage protection relay may trip, disconnecting the mains supply). After such an event, the alarm system will draw power from the backup battery, until all reserve power is exhausted, leaving the premises without protection.

**Telephone line trouble:** Telephone lines may be disconnected or short circuited. With the telephone line "down", your alarm system will not be able to report events to the central station.

Sirens do not always wake up sound sleepers: Sirens and bells installed outside or far from bedrooms are not likely to awaken people who are sound asleep behind closed doors inside the protected area or in adjacent buildings.

The system is sometimes defeated: With sufficient technical know-how, intruders may find a way to defeat various types of sensor or disconnect warning devices. Intruders may also take advantage of unprotected openings and skylights, or even enter forcibly at unpredictable spots.

**Smoke detectors have their limits:** In many cases, smoke detectors fail to warn on time because the fire started at a different level of the house, or too far away from the detector.

All this gives sufficient proof that even with a good alarm system installed, there is still need for life and property insurance. In addition, users should test their alarm systems at regular intervals, to make sure that malfunctions are detected before a true alarm event occurs.

#### **APPENDIX A. PARTITIONING**

PowerMaxComplete includes an optional partition feature. Partitioning is available only if your installer has enabled the feature. Once partitioning is enabled Partitioning menus are added to the system which can be viewed on the control panel's LCD display. Partitioning allows you to divide the system into three independently controllable areas with different users assigned to each partition whereby each user can arm the partition to which they are assigned.

Each user code can be assigned to a combination of up to 3 partitions and each partition can be armed or disarmed regardless of the status of the other partitions within the system. For example, you can define the garage as partition 1, the basement as partition 2, and the house as partition 3. Since each partition is independent of other partitions, you can arm or disarm each partition as desired without altering the states of the other partitions.

PowerMaxComplete also supports a situation where an area is used by two or more partitions. For example, a reception area which is common to two offices, each of which is assigned to a separate partition, will be armed only after both offices (partitions) are armed. In the armed state the reception area will be disarmed after either office (partitions) has been disarmed to allow the user of that office to use the reception area without generating an alarm. Such an area is termed a "common area".

#### **Selecting a Partition**

When operating in partition mode the first display will read:

P1: R P2: N P3: R

Press # n; the display will read:

**SELECT PARTITION** 

Press 1 2 and 3 to select the desired corresponding partition.

**Note:** After 5 seconds of no button press there will be a timeout and the display will revert to the All Partition display.

# **Arming / Disarming the System**

Before continuing, make sure that Partitioning has been enabled via the Installer Mode.

#### **Arming/Disarming All Partitions**

To arm/disarm all partitions in READY mode, press

#### **Arming/Disarming a Single Partition**

To arm/disarm a single partition, press the button on the control panel and then press the Partition number: 1; 2; or 3. Then, press the button.

#### The Show Function

The show function is enabled during single/all partition(s) status and displays information that is relevant to the selected or all partitions.

#### **Show All Partitions**

In Ready mode press ilok, the display will show information on all partitions. Press ilok repeatedly to view memory / status content.

#### **Show Single Partition**

In Ready mode, press # n and then press the partition number. The display will show information relevant to the selected partition. Press ilok repeatedly to view memory / status content

**Note:** After 5 seconds of no button press there will be a timeout and the display will revert to the all partition display.

# **APPENDICES**

#### Siren

A partition is alarmed when receiving an event from an alarmed device assigned to that partition. Alarmed devices do not affect partitions to which they are not assigned. A siren is common to all partitions; therefore, an alarm from one or more partitions will activate the siren.

#### **Siren Activity**

- The siren will be activated when receiving an event from an alarmed device.
- Overlapping siren activations from different partitions will not cause the duration of the siren to be extended.
- When the siren sounds, it will not stop until all alarmed partitions are disarmed. However if the siren is active due to an alarm from a common area zone, and one of the partitions assigned to this area disarms the system, the siren will also stop. In case that the alarm is initiated from a common area but continues with zones that are not assigned to a common area, the siren will not stop until all partitions assigned to the alarmed zones are disarmed.
- In case that there is a fire in partition 1 and a burglary in partition 2, the siren will sound FIRE. When partition 1 is disarmed the siren will sound BURGLAR for the remainder of the siren timeout period.

#### **Partition Status display**

Partitions status is indicated in the following manner:

P1:X P2:X P3:X

Each X value indicates a different partition state, as follows:

| R | Ready       |
|---|-------------|
| N | Not ready   |
| Α | Away        |
| Н | Home        |
| Е | Exit delay  |
| D | Entry delay |
| - | Not used    |

#### MCT-237


The MCT-237 two-way wireless keyfob is used to control single or all partitions.

#### **Arming/Disarming All Partitions**

To arm/disarm all partitions, press the HOME / AWAY / DISARM button on the keyfob.

#### **Arming/Disarming a Single Partition**

To arm/disarm a single partition, press the PARTITION SELECTION button on the keyfob once. In this state repeated pressing of the PARTITION SELECTION button will toggle between the enabled partitions and Partition All. To arm/disarm the desired partition(s), press the HOME/AWAY/DISARM button.



#### MCM-140+


The wireless remote commander is used to control single or all partitions.

#### **Arming/Disarming All Partitions**

To arm all partitions, press the HOME / AWAY / DISARM button followed by the user code.

#### Arming/Disarming a Single Partition

To arm/disarm a single partition, press the "LIGHT" button followed by the desired partition number (1, 2 or 3). When the red LED turns OFF, press the HOME/AWAY/DISARM button within 5 seconds followed by the user code.



#### MKP-150/151/152

The two-way wireless keypad is used to control single or all partitions and functions in the same way as the PowerMaxComplete control panel. See the section on "The Show Function" above (substitute the button with the  $\bigcirc$  button).

#### **MKP-160**

The touch screen keyprox can be used with any combination of partitions.

#### **Arming / Disarming Partition(s)**

Press the desired partitions buttons. When the selected keys blink, press the HOME / AWAY / DISARM button and then present your proximity tag.

# **APPENDICES**

#### APPENDIX B. GLOSSARY

This list of terms is arranged in alphabetical order. Any term indicated by cursive (italic) letters within the explanatory text can be looked up separately.

**Abort Period:** When an alarm is initiated, the internal sounder is activated first for a limited period of time which is the <u>abort period</u> set by the installer. If you cause an alarm accidentally, you can disarm the system within the abort period before the real sirens start and before the alarm is reported to the *remote responders*.

Alarm: There are 2 kinds of alarm:

<u>Loud alarm</u> - both internal and external sirens blare out constantly and the control panel reports the event by telephone.

<u>Silent alarm</u> - the sirens remain silent, but the control panel reports the event by telephone.

A state of alarm is caused by:

- Motion detected by a motion detector
- Change of state detected by a magnetic contact detector - a closed window or door is opened
- Detection of smoke by a smoke detector
- Tampering with any one of the detectors
- Pressing the two emergency buttons simultaneously (panic)

**Arming:** Arming the alarm system is an action that prepares it to sound an alarm if a zone is "violated" by motion or by opening a door or window, as the case may be. The control panel may be armed in various modes (see *AWAY*, *HOME*, *INSTANT* and *LATCHKEY*).

**AWAY:** This type of arming is used when the protected site is vacated entirely. All zones, *interior* and *perimeter* alike, are protected.

Chime Zones: Allow you to keep track of activity in the protected area while the alarm system is in the disarmed state. Whenever a chime zone is "opened", the buzzer beeps twice. The buzzer doesn't beep, however, upon closing the zone (return to normal). Residences can use this feature to annunciate visitors or look after children. Businesses can use it to signal when customers enter the premises or when personnel enter restricted areas.

**Note:** Your installer will never designate a 24-hour zone or a fire zone as a chime zone, because both zone types actuate an alarm if disturbed while the system is in the disarmed state.

Although one zone or more are designated as chime zones, you can still enable or disable the chime function.

Control Panel: The control panel is a cabinet that incorporates the electronic circuitry and microprocessor that control the alarm system. It collects information from various sensors, processes it and responds in various ways. It also includes the user-interface - control keys, numerical keypad, display, sounder and loudspeaker.

**Disarming:** The opposite of arming - an action that restores the control panel to the normal standby state. In this state, only *fire and 24-hour zones* will sound an alarm if violated, but a "panic alarm" may also be initiated.

**Disturbed Zone:** A zone in a state of alarm (this may be caused by an open window or door or by motion in the field of view of a motion detector). A disturbed zone is considered "not secured".

Forced Arming: When any one of the system zones is disturbed (open), the alarm system cannot be armed. One way to solve this problem is to find and eliminate the cause for zone disturbance (closing doors and windows). Another way to deal with this is to impose forced arming - automatic de-activation of zones that are still disturbed upon termination of the exit delay. Bypassed zones will not be protected throughout the arming period. Even if restored to normal (closed), bypassed zones will remain unprotected until the system is disarmed.

Permission to "force arm" is given or denied by the installer while programming the system.

**HOME:** This type of arming is used when people are present within the protected site. A classic example is night-time at home, when the family is about to retire to bed. With HOME arming, perimeter zones are protected but interior zones are not. Consequently, motion within interior zones will be ignored by the control panel, but disturbance of a perimeter zone will cause an alarm.

**Instant:** You can arm the system AWAY-INSTANT or HOME-INSTANT, thereby canceling the entry delay for all delay zones for the duration of one arming period.

For example, you may arm the control panel in the HOME-INSTANT mode and remain within the protected area. Only perimeter protection is active, and if you do not expect somebody to drop in while the system is armed, alarm upon entry via the main door is an advantage.

To disarm the system without causing an alarm, use your control keypad (which is normally accessible without disturbing a perimeter zone) or use a keyfob transmitter.

**Latchkey:** The Latchkey mode is a special arming mode in which designated "latchkey users" will trigger a "latchkey message" to be sent to a telephone when they disarm the system.

Note: This applies to latchkey users 5 to 8 only

For example, if a parent wants to be sure that their child has returned from school and disarmed the system. Latchkey arming is only possible when the system is armed in the AWAY mode.

Magnetic Contact Detector, Wireless: A Magnet-controlled switch and a wireless PowerCode transmitter in a shared housing. The detector is mounted on doors and windows to detect changes in state (from closed to open and vice versa). Upon sensing that a door or window is open, the detector transmits its unique identification code accompanied by an "alarm" signal and various other status signals to the control panel. The control panel, if not armed at that time, will consider the alarm system as "not ready for arming" until it receives a "restored" signal from the same detector.

**Motion Detector, Wireless:** A passive Infrared motion sensor and a wireless PowerCode transmitter in a shared housing. Upon sensing motion, the detector transmits its unique identification code, accompanied by an alarm signal and various other status signals to the control panel. After transmission, it stands by to sense further motion.

**Non-Alarm Zone:** Your installer can designate a zone for roles other than alarm. For instance, a motion detector installed in a dark stairway may be used to switch on lights automatically when someone crosses the dark area. Another example is a miniature wireless transmitter linked to a zone that controls a gate opening mechanism.

**Quick Arming:** Arming without a user code. The control panel does not request your user code when you press one of the arming buttons. Permission to use this arming method is given or denied by the installer while programming the system.

**Remote Responder:** A responder can be either a professional service provider to which the home or business owner subscribes (a central monitoring station) or a family relation/friend who agrees to look after the protected site during absence of its occupants. The control panel reports events by telephone to both kinds of responders.

**Restore:** When a detector reverts from the state of alarm to the normal standby state, it is said to have been "restored".

A *motion detector* restores automatically after detection of movement, and becomes ready to detect again. This kind of "restore" is not reported to the remote *responders*.

A *magnetic contact detector* restores only upon closure of the protected door or window. This kind of "restore" is reported to the remote *responders*.

**Smoke Detector, Wireless:** A regular smoke detector and a wireless PowerCode transmitter in a shared housing. Upon detection of smoke, the detector transmits its unique identification code accompanied by an alarm signal and various status signals to the *control panel*. Since the smoke detector is linked to a special *fire zone*, a fire alarm is initiated.

**User Codes:** The PowerMaxComplete is designed to obey your commands, provided that they are preceded by a valid security access code. Unauthorized people do not know this code, so any attempt on their part to *disarm* or defeat the system is bound to fail. Some operations, however, can be carried out without a user code as they do not degrade the security level of the alarm system.

**Zone:** A zone is an area within the protected site under supervision of a specific detector. During programming, the installer allows the *control panel* to learn the detector's identity code and links it to the desired zone. Since the zone is distinguished by number and name, the control panel can report the zone status to the user and register in its memory all the events reported by the zone detector. Instant and delay zones are "on watch" only when the control panel is armed, and other (24-hour) zones are "on watch" regardless of whether the system is armed or not.

# **APPENDICES**

#### APPENDIX C. HOME FIRE ESCAPE PLANNING

Fire can spread rapidly through your home, leaving you a short time to escape safely. Your ability to get out depends on advance warning from smoke detectors and advance planning - a home fire escape plan that everyone in your family is familiar with and has practiced.

- Pull together everyone in your household and make an evacuation plan.
- Draw a floor plan of your home, showing two ways out of each room, including windows. Don't forget to mark the location of every smoke detector.
  - Test all smoke detectors (by a qualified testing laboratory) periodically, to ensure to ensure their serviceability. Replace batteries as required.
- Make sure that everyone understands the escape plan and recognizes the sound of smoke alarm. Verify that the escape routes are clear and that doors and windows can be opened easily.
- If windows or doors in your home have security bars, make sure that the bars have quick-release mechanisms on the inside, so that they can be opened immediately in an emergency case. Quick release mechanisms won't compromise your security, but they will increase your chances of safely escaping a home fire.
- Practice the escape plan at least twice a year, making sure that everybody is involved from kids to grandparents. Allow children to master fire escape planning and practice before holding a fire drill at night when they are sleeping. The objective is to practice, not to frighten, so telling children there will be a drill before they go to bed can be as effective as a surprise drill. If children or others do not readily waken to the sound of the smoke alarm, or if there are infants or family members with mobility limitations, make sure that someone is assigned to assist them in fire drill and in the event of an emergency.

- Agree on an outside meeting place where everyone can meet after they've escaped. Remember to get out first, and then call for help. Never go back inside until the fire department gives the OK.
- Have everyone memorize the emergency phone number of the fire department. That way any member of the household can call from a cellular phone or a neighbor's home.
- Be fully prepared for a real fire: when a smoke alarm sounds, get out immediately and once you are out, stay bout - leave the firefighting to the professional!
- If you live in an apartment building, make sure that you are familiar wit the building evacuation plan. In case of a fire, use the stairs, never the elevator.

Tell guests or visitors to your home about your family's fire escape plan. When visiting other people's home, ask about their escape plan. If they don't have a plan in place, offer to help them make one. This is especially important when children are permitted to attend "sleepovers" at friends' homes.

#### **FCC STATEMENT**

The 315 MHz model of this device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received, including interference that may cause undesired operation.

The digital circuit of this device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio and television reception. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause such interference, which can be verified by turning the device off and on, the user is encouraged to eliminate the interference by one or more of the following measures:


- Re-orient or re-locate the receiving antenna.
- Increase the distance between the device and the receiver
- Connect the device to an outlet on a circuit different from the one which supplies power to the receiver.
- Consult the dealer or an experienced radio/TV technician.
   At 315 MHz (and 125 KHz of proximity tags) the product complies with FCC requirements.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be re-located or operating in conjunction with any other antenna or transmitter.

**Warning:** Changes or modifications to this equipment not expressly approved by Visonic Inc. could void the user's authority to operate the equipment.

# **Industry Canada Customer Information**

- 1. This equipment, wireless emergency response system, model "PowerMaxComplete", complies with Part 68 of the FCC Rules and the requirements adopted by the ACTA. On the bottom panel of this equipment is a label, that contains among other information, a product identifier in the format US:VSOAL03BPMCMPLETE. If requested, this number must be provided to the telephone company.
- This equipment is designed to be connected to the telephone network using RJ11 connector which complies with Part 68 rules and requirements adopted by ACTA and properly installed RJ31X connector. See Installation Instructions for details.
- 3. The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. The REN of alarm system is part of the product identifier that has the format US:VSOAL03BPMCMPLETE.
- 4. If the "PowerMaxComplete" causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, you will be notified as soon as possible. Also, you will be advised of your right to file a compliant with the FCC if it is necessary.
- 5. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.
- 6. If trouble is experienced with the "PowerMaxComplete" for repair or warranty information please contact Visonic Inc USA., 65 West Dudley Town Road, Bloomfield, CT 06002, phone number: 8 602 430 833, URL: www.visonic.com. If the equipment is causing harm to the telephone network, the telephone company may request to disconnect the equipment until the problem is resolved.
- 7. The "PowerMaxComplete" installation is described in the Installer Guide. Connection to telephone company provided coin service is prohibited. Connection to party lines service is subject to state tariffs.
- 8. Wireless alarm system must be able to seize the telephone line and place a call in an emergency situation. It must be able to do this even if other equipment (telephone, answering system, computer modem, etc.) already has the telephone line in use. To do so, "PowerMaxComplete" must be connected to a properly installed RJ31X jack that is electrically in series with and ahead of all other equipment attached to the same telephone line. Proper installation is depicted in the figure below. If you have any questions concerning these instructions, you should consult your telephone company or a qualified installer about installing the RJ31X jack and "PowerMaxComplete" for you.





#### W.E.E.E. Product Recycling Declaration

For information regarding the recycling of this product you must contact the company from which you originally purchased it. If you are discarding this product and not returning it for repair then you must ensure that it is returned as identified by your supplier. This product is not to be thrown away with everyday waste.

Directive 2002/96/EC Waste Electrical and Electronic Equipment.





INTERNET: ©VISONIC LTD. 2014 www.visonic.com

POWERMAXCOMPLETE PARTITION II USER GUIDE D-303984 (REV. 1, 6/14)

(UL file:BP9249)





